

# PUPPET ARMATURES FOR STOP-MOTION ANIMATION

Technical Design Guide

3D Printable Models for SLA Printing

Blender Python Script Included

Version 1.0 | 2025

# TABLE OF CONTENTS

## 1. Introduction to Puppet Armatures

Overview and applications

## 2. Technical Requirements for SLA Printing

Parameters and tolerances

## 3. Type 1: Wire Armature (Basic)

Simple construction for beginners

## 4. Type 2: Ball-and-Socket Armature (Professional)

Advanced joint system

## 5. Type 3: Modular Armature

Interchangeable components

## 6. Type 4: Hand Armature

Detailed finger articulation

## 7. Type 5: Universal Joints Set

Custom building blocks

## 8. Assembly Instructions

Step-by-step guide

## 9. Material Recommendations

Resin types and properties

## 10. Using the Blender Script

How to generate and export models

# 1. Introduction to Puppet Armatures

A puppet armature is the internal skeleton of a stop-motion puppet that provides structural support and enables controlled movement during animation. Unlike traditional ball-joint dolls or action figures, stop-motion armatures must maintain their pose precisely between frames without drifting or settling. This requires carefully designed friction joints that can be tightened or adjusted as needed throughout the animation process.

The art of stop-motion animation has evolved significantly since its early days in the 20th century. Modern armatures combine traditional craftsmanship with advanced manufacturing techniques, including 3D printing. SLA (Stereolithography) printing offers exceptional precision for creating small, detailed components that would be difficult or impossible to machine using traditional methods. This technology democratizes access to professional-quality armatures, allowing independent animators and small studios to create sophisticated puppet mechanisms without expensive machining equipment.

## Key Functions of an Armature:

Function	Description	Importance
Structural Support	Maintains puppet shape under gravity	Critical
Pose Control	Allows animator to position limbs precisely	Critical
Friction Retention	Holds position between frames	Critical
Attachment Points	Connects to puppet exterior materials	High
Replaceability	Allows part replacement if damaged	Medium

Table 1: Core Functions of Stop-Motion Armatures

# 2. Technical Requirements for SLA Printing

SLA printing uses a UV laser to cure liquid photopolymer resin layer by layer, creating highly detailed parts with smooth surface finishes. However, this process has specific limitations that must be considered when designing armature components. Understanding these constraints is essential for creating functional joints that operate smoothly after printing and post-processing.

## 2.1 Minimum Dimensions

Parameter	Minimum Value	Recommended	Notes
Wall thickness	0.4 mm	0.8-1.0 mm	Thinner walls may fail during printing
Pin/hole diameter	0.5 mm	1.0-2.0 mm	Critical for joint pivots
Gap between parts	0.1 mm	0.2-0.3 mm	Allows movement after curing

Ball joint diameter	3 mm	4-8 mm	Smaller balls wear quickly
Support contact area	N/A	>2 mm	Larger areas leave marks

Table 2: SLA Printing Dimension Constraints

## 2.2 Joint Tolerance Calculations

Proper joint tolerance is crucial for functional ball-and-socket connections. The gap between the ball and socket must be large enough to allow smooth rotation but small enough to maintain friction for pose retention. Our recommended formula accounts for resin shrinkage during curing, which typically ranges from 1-5% depending on the material and printing parameters used.

$$\text{Socket Inner Diameter} = \text{Ball Diameter} + 2 \times (\text{Tolerance} + \text{Shrinkage Compensation})$$

Where:

- Tolerance = 0.15-0.25 mm (minimum gap for movement)
- Shrinkage Compensation = 0.02-0.05 mm per mm of dimension
- For a 6 mm ball: Socket ID =  $6 + 2 \times (0.2 + 0.15) = 6.7 \text{ mm}$

## 3. Type 1: Wire Armature (Basic)

The wire armature represents the most accessible entry point into stop-motion puppet construction. This design uses a continuous wire skeleton that runs through the entire puppet body, with cross-bars at the shoulders and pelvis providing width and stability. While simpler than ball-and-socket designs, wire armatures remain widely used in professional animation studios for secondary characters and creatures where extreme precision is not required.

### 3.1 Design Specifications

Component	Dimension (15 cm puppet)	Material
Spine wire	2.0 mm diameter, 120 mm length	Aluminum or steel
Shoulder bar	2.4 mm diameter, 60 mm length	Aluminum or steel
Pelvis bar	2.4 mm diameter, 45 mm length	Aluminum or steel
Arm wires	1.5 mm diameter, 52 mm each	Aluminum
Leg wires	2.0 mm diameter, 67 mm each	Steel or aluminum
Head loop	2.0 mm diameter, 25 mm ring	Aluminum

Table 3: Wire Armature Component Specifications

### 3.2 Advantages and Limitations

Advantages: Low cost, simple construction, easy repairs, lightweight, flexible posing, no special tools required. Wire armatures can be built in a single day with basic materials from a hardware store. The continuous wire construction eliminates loose parts that could fail during animation sessions.

Limitations: Wire fatigue after repeated bending, limited pose precision, gradual drift in positions, difficulty maintaining extreme poses. Aluminum wire typically lasts 50-100 animation cycles before showing signs of fatigue, while steel wire lasts longer but is harder to bend smoothly.

## 4. Type 2: Ball-and-Socket Armature (Professional)

The ball-and-socket armature represents the professional standard for stop-motion animation. Each joint consists of a precision-ground ball captured in a socket, creating a connection that can rotate in any direction while providing adjustable friction. This design allows animators to make subtle incremental adjustments to poses while maintaining absolute position stability between frames.

### 4.1 Joint Anatomy

Each ball-and-socket joint comprises three primary components working together: the ball (spherical head attached to one bone segment), the socket (hemispherical cup attached to the adjacent segment), and the tensioning mechanism (typically a spring or screw system that adjusts clamping pressure). The friction between ball and socket determines how firmly the joint holds its position.

Joint Location	Ball Diameter	Socket Depth	Friction Range
Hip joints	6 mm	4.5 mm (75%)	High
Knee joints	6 mm	4.5 mm (75%)	Medium
Ankle joints	4 mm	3.0 mm (75%)	Medium
Shoulder joints	6 mm	4.5 mm (75%)	Medium
Elbow joints	4 mm	3.0 mm (75%)	Medium
Wrist joints	4 mm	2.5 mm (62%)	Low
Neck joint	6 mm	4.0 mm (67%)	Medium

Table 4: Ball-and-Socket Joint Specifications

### 4.2 Body Proportions

Body Segment	Percentage of Height	15 cm Puppet (mm)
Head height	15%	22.5 mm
Neck	3%	4.5 mm
Torso	20%	30 mm
Pelvis	5%	7.5 mm

Upper arm	12%	18 mm
Forearm + hand	12%	18 mm
Thigh	15%	22.5 mm
Shin + foot	15%	22.5 mm

Table 5: Human Proportion Standards for Puppet Design

## 5. Type 3: Modular Armature System

The modular armature system provides maximum flexibility by separating each functional component into individually printable parts. This approach allows animators to replace damaged sections, customize proportions, or experiment with different joint configurations without reprinting the entire armature. Modular designs also facilitate scaling, as components can be adjusted independently.

### 5.1 Module Categories

Module	Components	Connection Type
Pelvis Module	Central block, hip mounts, spine receiver	Threaded M2/M3
Chest Module	Ribcage block, shoulder mounts, neck receiver	Threaded M2/M3
Head Module	Skull dome, jaw pivots, neck rod	Press-fit or screw
Leg Modules (x2)	Thigh, knee, shin, ankle, foot segments	Ball-and-socket
Arm Modules (x2)	Upper arm, elbow, forearm, wrist, hand	Ball-and-socket

Table 6: Modular System Component Overview

## 6. Type 4: Hand Armature (Detailed Finger Articulation)

Hand animation is one of the most challenging aspects of stop-motion puppetry. Characters frequently need to interact with props, gesture expressively, or grip objects naturally. A dedicated hand armature provides individual control over each finger segment, enabling nuanced performances that would be impossible with simplified hand designs.

### 6.1 Finger Joint Configuration

Finger	Joints	Total Length	Range of Motion
Thumb	2 IP joints + CMC	70% of middle	Opposition + flexion
Index	3 joints (MCP, PIP, DIP)	95% of middle	Flexion + adduction
Middle	3 joints (MCP, PIP, DIP)	Reference (100%)	Flexion only

Ring	3 joints (MCP, PIP, DIP)	95% of middle	Flexion only
Pinky	3 joints (MCP, PIP, DIP)	80% of middle	Flexion + abduction

Table 7: Finger Joint Anatomy for Animation

## 7. Type 5: Universal Joints Set

For animators who prefer to design their own custom armatures, the Universal Joints Set provides a collection of standardized components that can be mixed and matched. This approach is ideal for creating non-humanoid characters, creatures, or specialized mechanisms that don't fit standard proportions.

### 7.1 Available Component Sizes

Size Name	Ball Diameter	Socket ID	Recommended Use
Small	4 mm	4.4 mm	Fingers, toes, facial features
Medium	6 mm	6.5 mm	Elbows, knees, wrists
Large	8 mm	8.6 mm	Hips, shoulders, spine

Table 8: Universal Joint Component Specifications

## 8. Assembly Instructions

### 8.1 Post-Printing Preparation

Before assembly, all printed parts require proper post-processing to ensure optimal joint performance. This includes UV curing, support removal, and surface finishing. The quality of post-processing directly affects joint friction and long-term durability of the armature.

1. Remove prints from build plate carefully using a plastic scraper
2. Submerge parts in IPA (99% isopropyl alcohol) for 10-15 minutes
3. Use ultrasonic cleaner for complex parts with internal channels
4. Remove supports while resin is still soft (before final cure)
5. Sand mating surfaces with 400-600 grit sandpaper
6. UV cure for 10-30 minutes depending on resin type
7. Apply silicone-based lubricant to ball surfaces before assembly
8. Test joint friction and adjust with fine sandpaper if needed

## 8.2 Joint Assembly Sequence

Assemble joints in a systematic order, starting from the pelvis and working outward. This ensures proper alignment and allows for adjustments during the build process. Keep all fasteners and tools organized before beginning assembly.

Step	Action	Tools Required
1	Assemble pelvis block with hip sockets	M2 hex key, pliers
2	Attach leg segments to hip joints	Hex key, silicone grease
3	Connect knee and ankle joints	Pliers, alignment jig
4	Attach spine to pelvis	M2 screwdriver
5	Mount chest block on spine	Hex key
6	Install shoulder joints	Pliers, grease
7	Attach arm segments	Alignment tools
8	Connect neck and head	M2 screwdriver

Table 9: Assembly Sequence for Complete Armature

## 9. Material Recommendations

### 9.1 Resin Types for Armature Parts

Resin Type	Properties	Best For	Notes
Standard	Good detail, moderate strength	Bones, structural parts	May brittle over time
Tough	High impact resistance	Joint components	Requires longer cure
Flexible	Elastic, rubber-like	Socket interiors	Limited precision
Engineering	Heat resistant, strong	High-wear joints	Higher cost
Dental	Extreme precision	Small ball joints	Specialized equipment

Table 10: Resin Selection Guide for Armature Components

## 10. Using the Blender Script

### 10.1 Installation and Setup



The provided Python script generates all five armature types directly in Blender. Follow these steps to load and execute the script within Blender's Python environment. The script is compatible with Blender 3.0 and later versions.

1. Open Blender (version 3.0 or later recommended)
2. Navigate to the Scripting workspace (top menu bar)
3. Click 'New' to create a new text block
4. Copy the entire contents of 'puppet\_armatures\_blender.py'
5. Paste into the text editor
6. Press 'Run Script' (Alt+P) or click the play button
7. Wait for model generation (typically 5-10 seconds)
8. All armatures will appear in the 3D viewport

## 10.2 Export Options

After generating models, export them for 3D printing using Blender's built-in exporters. STL format is recommended for SLA printers, though OBJ with metric units also works well. When exporting, ensure the scale factor is set correctly for your printer's expected units (typically millimeters).

Format	Use Case	Scale Setting
STL	Most SLA slicers (Chitubox, Lychee)	x1000 (m to mm)
OBJ	Autodesk applications, Formlabs PreForm	x1000 (m to mm)
3MF	Modern slicers with unit support	x1000 (m to mm)
AMF	Multi-material printers	x1000 (m to mm)

Table 11: Export Format Recommendations

## 10.3 Customization Tips

The script includes adjustable parameters at the top of the file. Key values that can be modified include the overall puppet scale (default 15 cm), ball joint diameters for different body parts, and tolerance values for joint fit. When modifying these values, maintain proportional relationships between components to ensure proper assembly.

Key parameters to adjust:

- DOLL\_SCALE: Overall puppet height in meters (default: 0.15 for 15 cm puppet)
- MIN\_WALL\_THICKNESS: Minimum printable wall (default: 0.001 m = 1 mm)
- JOINT\_TOLERANCE: Gap between ball and socket (default: 0.0002 m = 0.2 mm)
- BALL\_SMALL/MEDIUM/LARGE: Joint ball diameters in meters